



※図はRネジタイプを表示

ホース	ねじ	コード	品名	H	B	C	F	J	L	CL
6	R1/4	6422935	GXS1-04	19	13	32	-	-	60	40
	G1/4B	6420135	GXS2R-04	19	10.5	30	-	-	57	37
	R1/4	6430163	GX45S1-04(210K)	19	13	31	34	60	84	64
	G1/4B	6430161	GX45S2R-04(210K)	19	10.5	29	32	58	82	62
	R1/4	6430164	GX90S1-04(210K)	19	13	31	48	32	56	37
	G1/4B	6422934	GX90S2R-04	19	10.5	29	45	32	56	37
	G1/4B	6422929	GX90S2R-065-04	19	10.5	29	65	32	56	37
9	R3/8	6422932	GXS1-06	22	15	37	-	-	65	45
	G3/8B	6420136	GXS2R-06	22	10.7	33	-	-	60	41
	R3/8	6425102	GX45S1-06	22	15	36	39	62	86	66
	G3/8B	6430168	GX45S2R-06	22	10.7	31	36	59	83	63
	R3/8	6430169	GX90S1-06	22	15	36	55	34	58	39
	G3/8B	6422931	GX90S2R-06	22	10.7	31	51	34	58	39
	G3/8B	6422930	GX90S2R-074-06	22	10.7	31	74	54	78	59
12	R1/2	6422933	GXS1-08 A	27	18	40	-	-	78	50
	G1/2B	6420137	GXS2R-08	27	14.5	37	-	-	75	46
	R1/2	6430581	GX45S1-08(210K)	27	18	39	46	70	105	76
	R1/2	6430322	GX90S1-08	27	18	39	65	50	85	56
	G1/2B	64202111	GX90S2R-08	27	14.5	35	61	50	85	56
	G1/2B	6422936	GX90S2R-089-08	27	14.5	35	89	55	90	61
15										
19										
25										

CL:ホース切断時に差し引く長さ(参考値)